

KWSL2000RM-1 part list

P/N	Description	Quantity
1	Nut M12	1
2	Spring Washer $\phi 12$	2
3	Washer $\phi 13$	1
4	Drive Gear (big)	1
5	Shaft Sleeve	2
6	Bearing	2
7	Washer $\phi 15$	4
8	Panel (small)	1
9	Panel (big)	1
10	Shaft	1
11	Wire Rope	1
12	Semicircle Parts	1
13	Spring	1
14	Aluminum Connecting Head	1
15	Hook	1
16	Dam-board	2
17	Nut M12	1
18	Handle Bar	1
19	Handwheel	1
20	Friction Pressure Plate	2
21	Friction Plate	2
22	Friction Gear	2
23	Flat Washer $\phi 10$	3
24	Long Shaft Sleeve	2
25	Long Bearing	2
26	Screw M5*8	1
27	Long Shaft	1
28	Drive Gear (small)	3
29	Spring Washer $\phi 10$	4
30	Nut M10	4
31	Connection Plate	1
32	Screw M4*8	1
33	Flat Washer $\phi 4$	5
34	Drive Shaft	1
35	Screw M4*45	1
36	Spring	1
37	Screw	1
38	Flat Washer $\phi 6$	1
39	Nut M6	1

P/N	Description	Quantity
40	Screw M3*15	3
41	Lever	1
42	Flat Washer $\phi 3$	7
43	Flat Washer $\phi 3$	1
44	Nut M3	1
45	Microswitch	1
46	Nut M8	1
47	Spring Washer $\phi 8$	1
48	Stop Pawl Torsion Spring	1
49	Stop Pawl	1
50	Stop Pawl Shaft	1
51	Washer M12	1
52	Screw M5*12	4
53	Flat Washer $\phi 5$	4
54	Flat Washer $\phi 10$	1
55	Duplex Gear	1
56	Duplex Gear Shaft	1
57	Washer D12	1
58	Screw M5*10	2
59	Washer $\phi 10$	2
60	Static Shaft	1
61	Rope Retaining Shaft	1
62	Pin $\phi 1.2$	3
63	Housing (Right)	1
64	Motor Assembly	1
65	Frame Assembly	1
66	Nut M5	2
67	Screw M5*16	3
68	Tension Plate	1
69	Connection Plate Screw	3
70	Hand Hold Part	1
71	Screw M4*20	2
72	Housing (Left)	1
73	Screw M4*35	1
74	Handle Switch Assembly	1
75	Hand Saver Strap	1
76	Power lead	1
77	Solenoid	1
78	Circuit Breaker	1

