




KT3000-1 part list

P/N	Description	Quantity
1	Screw M6*18	4
2	Clutch Knob	1
3	Pulley Hook	1
4	Gearbox Housing	1
5	Nut M8	4
6	O-Ring $\phi 98.6$	1
7	Clutch knob base	1
8	Self-Tapping Screw(ST4*8)	1
9	Fork pin	1
10	2nd Planetary Gear Assembly	1
11	Bulkhead	1
12	3rd Planetary Gear Assembly	1
13	O-Ring $\phi 26$	2
14	Gearbox Cover	2
15	Screw M6*10	4
16	Sliding Bearing	2
17	Gasket Ring	2
18	Drive Shaft	1
19	Circlip $\phi 7$	1
20	Clutch Spring	1
21	Screw M6*8	1
22	Tie bar	2
23	Drum	1
24	1st Planetary Gear Assembly	1
25	Screw M4*8	6
26	Brake Base	1
27	Brake Caliper	1

P/N	Description	Quantity
28	Brake Spring	1
29	Brake block	1
30	Brake Housing	1
31	Motor Base	1
32	Motor Assembly	1
33	Mounting Plate	1
34	Screw M8*20	2
35	Roller Fairlead	1
36	Flat Washer $\phi 8$	2
37	Spring Washer $\phi 8$	2
38	Nut M8	2
39	Wire Rope	1
40	Hook	1
41	Flat Washer $\phi 8$	4
42	Spring Washer $\phi 8$	4
43	Screw M8*25	4
44	Motor Lead (Yellow)	1
45	Motor Lead (Blue)	1
46	Battery Lead (Long and Short)	1
47	Circuit Breaker	1
48	Battery Lead (Black)	1
49	Hand Saver Strap	1
50	Waterproof Sleeve	6
51	Switch Holder	1
52	Switch Assembly	1
53	Solenoid	1