



KU60032-1 part list

P/N	Description	Quanatity
1	Screw M6*25	2
2	Screw M6*20	4
3	Motor Assembly	1
4	Motor Base	1
5	Tie bar	2
6	Drive Shaft	1
7	Gearbox Cover	1
8	O-Ring $\phi 95$	1
9	3rd Planetary Gear Assembly	1
10	Retainer Ring	1
11	Ring Gear	1
12	Bulkhead	1
13	2nd Planetary Gear Assembly	1
14	1st Planetary Gear Assembly	1
15	Bearing	1
16	Gearbox Housing	1
17	Clutch Slice	3
18	Clutch Bace	1
19	Clutch Pin	3
20	Clutch Cover	1
21	Screw M4*8	3
22	Self-Tapping Screw(ST4*8)	1
23	Clutch Knob	1
24	Clutch Pin Spring	6
25	Bottom Tie bar (BS)	1
26	Drum	1
27	Sliding Bearing	2
28	Gasket Ring	2

P/N	Description	Quanatity
29	Brake Assembly	1
30	Wire Rope	1
31	Hook	1
32	Hand Saver Strap	1
33	Screw M5*8	3
34	Tension Plate	1
35	Screw M8*20	2
36	Roller Fairlead	1
37	Nut M8	2
38	Mounting Plate	1
39	Flat Washer $\phi 8$	6
40	Spring Washer $\phi 8$	6
41	Screw M8*25	4
42	7 Pin Socket	1
43	Socket Cover	1
44	Control Box Top Cover	1
45	Solenoid	1
46	Control Box Base Cover	1
47	Control Box Holder(Left)	1
48	Control Box Holder(Right)	1
49	Handle Switch Assembly	1
50	Circuit Breaker	1
51	Circuit Breaker Connection Plate	2
52	Power lead(Black/Long)	1
53	Power lead(Black/Short)	1
54	Power lead(Red/Long)	1
55	Power lead(Red/Short)	1
56	Pulley Hook	1