

INSTALLATION INSTRUCTIONS FOR KTA14125 WIRELESS REMOTE SWITCH

Optional accessories for KT2500, KT3000, KT4000 series winches.

⚠ WARNING ⚠

WHEN OPERATING THE WIRELESS REMOTE MAKE SURE NO ONE OR THING IS NEAR THE WINCH AND OR WINCH CABLE.

⚠ WARNING ⚠

ALWAYS DISCONNECT WINCH POWER LEADS TO BATTERY BEFORE WORKING ON OR AROUND THE WINCH DRUM SO THAT WINCH CANNOT BE TURNED ON ACCIDENTALLY.

⚠ WARNING ⚠

BATTERIES CONTAIN GASES, WHICH ARE FLAMMABLE AND EXPLOSIVE. WEAR EYE PROTECTION DURING INSTALLATION AND REMOVE ALL METAL JEWELRY. DO NOT LEAN OVER BATTERY WHILE MAKING CONNECTIONS.

If you have purchased a KT4000, or have installed a KTA14103, on a KT2500, KT3000, or KT4000 Series, skip to step 7.

1. Your wireless remote comes with a base unit (1), pigtail connector plug (2) and 2 remote controls (3).



2. DISCONNECT BATTERY FROM WINCH AT THIS TIME.

3. To connect the wireless remote switch to your winch follow the diagram on the right.

NOTE: IF YOU ARE INSTALLING ON A KT2500 OR KT3000 SERIES WINCH, REMOVE THE OLD BULLET CONNECTORS ON THE SOLENOID.

4. Install the pigtail connector plug by following the wiring diagram marked "A".
5. Pay particular attention to the wire colors.

NOTE: MAKE SURE THE WIRES ARE NOT NEAR OR TOUCHING ANY HOT MATERIALS ON THE VEHICLE, AVOID ANY ENGINE, EXHAUST, COOLING SYSTEMS, AND ANY MOVING PARTS ON THE VEHICLE.

6. When attaching ring terminals to the winch solenoid, remove nuts on solenoid posts carefully. Use a wrench on the lower nut on the solenoid post and do not allow the post to turn when removing the top nut.



www.trakkerwinch.com

For more information contact Customer Service at: 800-533-7372 or email us at sales@hamptonproducts.com

HAMPTON PRODUCTS INTERNATIONAL INC. 50 Icon, Foothill Ranch, CA 92610-3000

HAMPTON PRODUCTS INTERNATIONAL INC. IS NOT LIABLE FOR ANY MISUSE OF THIS PRODUCT

7. After pigtail connector is installed, plug wireless remote base unit to the pigtail plug.
8. Your wireless remote switch is now installed.
9. Reconnect battery to winch.
10. Before activating winch, put winch in freewheel mode, pull out 2-3 feet of winch cable and reengage freewheel. Now press button on remote to identify cable in and cable out directions.
11. Your wireless remote is now installed. Enjoy your TRAKKER® winching experience.

NOTE: IF YOU ARE CONNECTING A HANDLE BAR ROCKER SWITCH "B", FOLLOW WIRING INSTRUCTIONS AND CONNECT 3 BULLET CONNECTORS TO THE WIRELESS REMOTE PIGTAIL.

