


## Solenoid Wiring Diagram for KV & KW



- Red small wire to large center post with large Red Cable is the power wire to the handheld controller or wireless receiver plug, and the large Red Cable is coming from the battery.
- Two black wires to the center small post would be ground
- The white (left hand small post) and the blue (right hand small post) are energized with positive to either retract or extend the winch.